


Mat. - Nr. - Konstante  
3740 . . . . .

Gebrauchs-/  
Aufstelanweisung  
59 1830  
(DE)

- 1) 44 0829  
(DE,EN)
- 2) 42 3941  
V01  
60 0110  
V02








Mat. – Nr. – Konstante  
3740 . . . . .

Mat. - Nr. - Konstante  
3740 . . . . .



<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0010	00067332	00621463	Foot
0020	00084713	00655300	Holder
0030	00141874	00145787	Pump-drain
0040	00141875	00144797	Motor
0050	00163750		Ball bearing
0070	00167581		Holder
0080	00167587	00067083	Holder
0090	00170961		Sensor-NTC
0100	00171253	00481580	Power cord
0110	00171254	00623842	Capacitor-interference suppre.
0120	00171270		Screw
0130	00171271		Screw
0140	00171272		Fixture
0150	00171273		Holder
0160	00171275	00606818	Spring-tank
0170	00171291	00613082	Shaft seal
0180	00172394	00421488	fastening ring
0190	00172395	00603523	fastening ring
0200	00172688	00448032	Shock absorber
0210	00172699		Knob-programme
0220	00172700		Knob-RPM
0230	00181184		Hose-vent
0240	00182154		Electric lock
0250	00182194		Lid
0260	00186869	00429205	Transit bolt
0270	00186870		Transit bolt
0290	00214720		Weight

0300	00214721	00773470	Weight
0310	00215113	00773699	Drum
0320	00218343		Worktop
0330	00235501	00715100	Tub
0340	00235567		Front panel
0350	00236013		Tub
0360	00241219	00711567	Housing
0370	00263501	00702594	Float
0380	00265958		Hose-fill
0390	00265961		Heating element
0400	00265964		Sealing
0410	00265965		Band
0420	00268281	00428211	Valve-magnet
0430	00268336		Hose-overflow
0440	00289822		Support
0450	00354126	00439671	fastening ring
0460	00354130	11002942	Pulley
0470	00354134		fastening ring
0480	00354135		Boot gasket
0510	00358305		Hose
0520	00358306		Outlet hose
0530	00358923		Rail
0540	00358931	00435791	Rail
0550	00360829	00439490	Belt-drive
0560	00366743	00704767	Aquastop
0570	00434099		Rail
0580	00436816		Case-rear part
0630	00354128	11020392	Window
0640	00171255		Axis

0650	00171264		Bushing
0660	00171269		Hinge-window
0670	00171278	00634207	Latch
0680	00369605		Frame-window
0690	00490903		Handle
0700	00432074		Frame-window
0710	00354123		Dispenser tray
0720	00354122		Dispenser tray-lower part
0730	00265957		Dispenser tray-upper part
0740	00423701		Cable harness
0750	00423702		Cable harness
0760	00423704		Cable harness
0770	00423938		Cable harness
0780	00423939		Cable harness
0790	00480442		Eco-hose-sump