


Mat. - Nr. - Konstante
3740


Gebrauchsanweisung
52 9467
(GB)

Programmtabelle
52 9515
(GB)




Mat. - Nr. - Konstante
3740

1) 35 5528



Mat. - Nr. - Konstante
3740

1) 26 5964
Set



Position ID	Spare part no.	Replacement	Description
0001	00066788		Holder
0002	00067332	00621463	Foot
0003	00068337		Holder
0004	00095209		Holder
0005	00141874	00145787	Pump-drain
0006	00150871		Terminal
0008	00170961		Sensor-NTC
0009	00165362		Cover
0010	00167581		Holder
0011	00167587	00067083	Holder
0012	00168813		Transit bolt
0013	00168814	00600388	Distance holder
0014	00171254	00623842	Capacitor-interference suppre.
0015	00171256	00182154	Electric lock
0016	00171261	00428210	Valve-magnet
0017	00171262		Hose-valve/soap box
0018	00171265	00491919	Hose-pressure chamber
0019	00171267		Holder
0020	00171270		Screw
0021	00171271		Screw
0022	00171272		Fixture
0023	00171273		Holder
0024	00171275	00606818	Spring-tank
0025	00171291	00613082	Shaft seal
0026	00172394	00421488	fastening ring
0027	00172395	00603523	fastening ring
0028	00214718	00218343	Worktop

0029	00214720		Weight
0030	00214721	00773470	Weight
0031	00215113	00773699	Drum
0032	00235499	00714215	Tub at rear
0033	00235501	00715100	Tub
0035	00235567		Front panel
0036	00265958		Hose-fill
0037	00265961		Heating element
0038	00265965		Band
0039	00266752		Cover
0040	00266859	12013467	Hose-inlet
0041	00289822		Support
0042	00354124		Outlet hose
0043	00354126	00439671	fastening ring
0044	00354130	11002942	Pulley
0045	00354134		fastening ring
0046	00354135		Boot gasket
0048	00355645		Case-rear part
0049	00360829	00439490	Belt-drive
0051	00480443		Eco-hose-sump
0054	00529467		Instruction manual
0055	00172696	00423704	Cable harness
0056	00172694		Cable harness
0057	00172695	00423701	Cable harness
0058	00268118	00432218	Control module
0059	00172697		Coupling
0060	00080451	00493529	Floor Securing Component
0061	00358923		Rail
0062	00358931	00435791	Rail

0063	00171278	00634207	Latch
0064	00171255		Axis
0065	00266751		Handle
0066	00354129	00366232	Frame-window
0067	00354128	11020392	Window
0068	00354127	00715042	Ring
0069	00172693	00600925	Regulator-water level
0070	00265959	00480443	Eco-hose-sump
0071	00171263		Ball-sump
0072	00168817	00424981	Pressure chamber
0073	00354123		Dispenser tray
0074	00354122		Dispenser tray-lower part
0075	00265957		Dispenser tray-upper part
0076	00265963		Fixing kit
0077	00265964		Sealing
0078	00172686		Bearing set
0079	00141875	00144797	Motor
0080	00168798		Holder
0081	00171269		Hinge-window
0082	00266748	00267678	Tray handle-dispenser
0083	00172699		Knob-programme
0084	00172700		Knob-RPM
0085	00172697		Coupling
0086	00172698		Coupling
0087	00172688	00448032	Shock absorber
0088	00172719		Cover
0089	00154740		Carbon-brush
0090	00173028		Carbon-brush
0091	00173028		Carbon-brush