


Mat. - Nr. - Konstante  
3740 . . . . .

Gebrauchsanweisung  
58 2776  
(IL)

Programmtabelle  
58 2777  
(IL)




Mat. - Nr. - Konstante  
3740 . . . . .

- 1) 35 5528
- 2) 16 8813  
V01
- 3) 18 6869  
V02
- 4) 16 8814  
V01
- 5) 18 6870  
V02



Mat. - Nr. - Konstante  
3740 . . . . .



|   | ASKOLL  | COPRECI |
|---|---------|---------|
| 1 | 17 2340 | 17 2337 |
| 2 | 15 1408 | 15 4358 |
| 3 | _____   | 172338  |
| 4 | 15 1409 | _____   |
| 5 | _____   | 17 2339 |

| <b>Position ID</b> | <b>Spare part no.</b> | <b>Replacement</b> | <b>Description</b>             |
|--------------------|-----------------------|--------------------|--------------------------------|
| 0001               | 00066788              |                    | Holder                         |
| 0002               | 00067332              | 00621463           | Foot                           |
| 0003               | 00068337              |                    | Holder                         |
| 0004               | 00095209              |                    | Holder                         |
| 0005               | 00141874              | 00145787           | Pump-drain                     |
| 0006               | 00150871              |                    | Terminal                       |
| 0007               | 00165362              |                    | Cover                          |
| 0008               | 00167581              |                    | Holder                         |
| 0009               | 00167587              | 00067083           | Holder                         |
| 0010               | 00168813              |                    | Transit bolt                   |
| 0011               | 00168814              | 00600388           | Distance holder                |
| 0012               | 00170961              |                    | Sensor-NTC                     |
| 0013               | 00171254              | 00623842           | Capacitor-interference suppre. |
| 0014               | 00171256              | 00182154           | Electric lock                  |
| 0015               | 00171261              | 00428210           | Valve-magnet                   |
| 0016               | 00171262              |                    | Hose-valve/soap box            |
| 0017               | 00171265              | 00491919           | Hose-pressure chamber          |
| 0018               | 00171267              |                    | Holder                         |
| 0019               | 00171270              |                    | Screw                          |
| 0020               | 00171271              |                    | Screw                          |
| 0021               | 00171272              |                    | Fixture                        |
| 0022               | 00171273              |                    | Holder                         |
| 0023               | 00171275              | 00606818           | Spring-tank                    |
| 0024               | 00172394              | 00421488           | fastening ring                 |
| 0025               | 00172395              | 00603523           | fastening ring                 |
| 0026               | 00214718              | 00218343           | Worktop                        |
| 0027               | 00214720              |                    | Weight                         |

|      |          |          |                          |
|------|----------|----------|--------------------------|
| 0028 | 00214721 | 00773470 | Weight                   |
| 0029 | 00235502 | 00241627 | Tub                      |
| 0031 | 00235567 |          | Front panel              |
| 0032 | 00238921 |          | Tub at rear              |
| 0033 | 00236611 | 00215117 | Drum                     |
| 0034 | 00265958 |          | Hose-fill                |
| 0035 | 00265961 |          | Heating element          |
| 0036 | 00265965 |          | Band                     |
| 0037 | 00266752 |          | Cover                    |
| 0038 | 00266859 | 12013467 | Hose-inlet               |
| 0039 | 00289822 |          | Support                  |
| 0040 | 00181184 |          | Hose-vent                |
| 0041 | 00354126 | 00439671 | fastening ring           |
| 0042 | 00354130 | 11002942 | Pulley                   |
| 0043 | 00354131 | 00678914 | Belt-drive               |
| 0044 | 00354134 |          | fastening ring           |
| 0045 | 00354135 |          | Boot gasket              |
| 0047 | 00355645 |          | Case-rear part           |
| 0048 | 00480443 |          | Eco-hose-sump            |
| 0049 | 00266722 | 00481580 | Power cord               |
| 0050 | 00529465 |          | Instruction manual       |
| 0053 | 00172696 | 00423704 | Cable harness            |
| 0054 | 00172694 |          | Cable harness            |
| 0055 | 00172695 | 00423701 | Cable harness            |
| 0056 | 00483971 | 00432218 | Control module           |
| 0057 | 00172697 |          | Coupling                 |
| 0058 | 00080451 | 00493529 | Floor Securing Component |
| 0059 | 00358923 |          | Rail                     |
| 0060 | 00358931 | 00435791 | Rail                     |

|      |          |          |                           |
|------|----------|----------|---------------------------|
| 0061 | 00171278 | 00634207 | Latch                     |
| 0062 | 00171255 |          | Axis                      |
| 0063 | 00266751 |          | Handle                    |
| 0064 | 00354129 | 00366232 | Frame-window              |
| 0065 | 00354128 | 11020392 | Window                    |
| 0066 | 00354127 | 00715042 | Ring                      |
| 0067 | 00188918 | 00427040 | Regulator-water level     |
| 0068 | 00265959 | 00480443 | Eco-hose-sump             |
| 0069 | 00171263 |          | Ball-sump                 |
| 0070 | 00168817 | 00424981 | Pressure chamber          |
| 0071 | 00354123 |          | Dispenser tray            |
| 0072 | 00354122 |          | Dispenser tray-lower part |
| 0073 | 00265957 |          | Dispenser tray-upper part |
| 0074 | 00265963 |          | Fixing kit                |
| 0075 | 00265964 |          | Sealing                   |
| 0076 | 00172685 |          | Bearing set               |
| 0077 | 00172692 | 00613083 | Shaft seal                |
| 0078 | 00141876 | 00145563 | Motor                     |
| 0079 | 00168798 |          | Holder                    |
| 0080 | 00172699 |          | Knob-programme            |
| 0083 | 00358304 |          | Container return          |
| 0084 | 00358305 |          | Hose                      |
| 0085 | 00358306 |          | Outlet hose               |