


Mat. – Nr. – Konstante  
3740 . . . . .

Gebrauchsanweisung  
58 8593  
(TR)


Programmtabelle  
58 8597  
(TR)

1) Sticker Belende  
17 3432  
(TR)



Mat. - Nr. - Konstante  
3740 . . . . .


- 1) 35 5528
- 2) 16 6869
- 3) 18 6870



Mat. - Nr. - Konstante  
3740 . . . . .

- 1) 26 5964 Set
- 2) 23 5500
- 3) 23 5502

Mat. - Nr. - Konstante  
3740 . . . . .



	ASKOLL	COPRECI
1)	17 2340	17 2337
2)	15 1408	15 4358
3)	_____	172338
4)	15 1409	_____
5)	_____	17 2339

<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0001	00241219	00711567	Housing
0002	00067332	00621463	Foot
0003	00068337		Holder
0004	00084713	00655300	Holder
0005	00142370	00145787	Pump-drain
0006	00150871		Terminal
0008	00167581		Holder
0009	00167587	00067083	Holder
0010	00170961		Sensor-NTC
0011	00171253	00481580	Power cord
0012	00171254	00623842	Capacitor-interference suppre.
0013	00171256	00182154	Electric lock
0014	00171261	00428210	Valve-magnet
0015	00171262		Hose-valve/soap box
0016	00171267		Holder
0017	00171270		Screw
0018	00171271		Screw
0019	00171272		Fixture
0020	00171273		Holder
0021	00171275	00606818	Spring-tank
0022	00172394	00421488	fastening ring
0023	00172395	00603523	fastening ring
0025	00186869	00429205	Transit bolt
0026	00186870		Transit bolt
0028	00214720		Weight
0029	00215114	00475501	Weight
0030	00235500		Tub at rear

0031	00235502	00241627	Tub
0032	00235567		Front panel
0033	00236611	00215117	Drum
0034	00238449		Desk top
0035	00265958		Hose-fill
0036	00266752		Cover
0037	00266859	12013467	Hose-inlet
0038	00268663		Clamp
0039	00289822		Support
0040	00354124		Outlet hose
0041	00354126	00439671	fastening ring
0042	00354130	11002942	Pulley
0043	00354131	00678914	Belt-drive
0044	00354134		fastening ring
0045	00354135		Boot gasket
0047	00355529		Window
0048	00354129	00366232	Frame-window
0049	00354127	00715042	Ring
0050	00354128	11020392	Window
0051	00266751		Handle
0052	00171255		Axis
0053	00171264		Bushing
0054	00171269		Hinge-window
0055	00171278	00634207	Latch
0056	00358923		Rail
0057	00358931	00435791	Rail
0058	00436816		Case-rear part
0059	00142369	00145563	Motor
0060	00265957		Dispenser tray-upper part

0061	00354122		Dispenser tray-lower part
0062	00354123		Dispenser tray
0063	00172685		Bearing set
0064	00265964		Sealing
0065	00172688	00448032	Shock absorber
0066	00265961		Heating element
0068	00266748	00267678	Tray handle-dispenser
0069	00172697		Coupling
0070	00188918	00427040	Regulator-water level
0071	00172699		Knob-programme
0072	00488283		Power module
0075	00265959	00480443	Eco-hose-sump